



Skirted Tub Installation Instructions

- Each tub is fitted with a 1x4 that extends the length of the tub to protect it during shipping. As per the diagram below, this must be installed to the studs, underneath the tub to hold it underneath the tub to hold it level and give it support.
- Place tub in desired opening and shim it to be level.
- Mark a line on the studs where the tile flange ends.
- Measure from the top of the tile flange to the bottom of the outside fiberglass edge. Transpose that measurement to the wall and draw a new level line on the wall.
- Install 1 x 4 cleat on the wall for the tub to rest on at the appropriate mark that you have just drawn on the wall.
- Prepare drain fittings.
- Mix thin set mortar and pile around the center sections of the shower base and also the bathing well of the tub.
- Place unit back into desired opening.
- Rock gently back and forth to work mortar mix out of the way until unit comes to rest on the leveling cleat that is installed on studs.
- Drill holes through the acrylic and fiberglass into the adjoining studs.
- Secure to studs with 1 ½ screws.

It is recommended that all of our products be installed on a bed of thin set concrete or mortar mix. This will stop any shifting or squeaking, and remove potential leak problems caused from flexing of the shower base or bathtub.

The Paliser 42" x 96"

